

## Interface Cable/Software Compatibility Information

Certain interface cables will only operate with specific loggers. The following information will help with determining the correct interface cable for your MadgeTech logger.

### Quick Reference Table

	IFC200	IFC110	IFC102	IFC103	IFC202	IFC300	RFC101A
Standard Data Loggers (All MadgeTech Data Loggers except those listed in this table)	•	•					
Cryo-Temp						•	
TransiTemp-EC (Single and Multi Use)				•			
TransiTempII, TransiTempII-RH, Wine Safe						•	
MicroTemp & MicroRHTemp					•		
RF Series Loggers	•	•					•

MadgeTech, Inc.  
 (603) 456-2011 Phone  
 (603) 456-2012 Fax  
[www.madgetech.com](http://www.madgetech.com)  
[support@madgetech.com](mailto:support@madgetech.com)

879 Maple Street,  
 Contoocook, NH 03229

PO Box 50  
 Warner NH 03278

### Cable Descriptions

#### **IFC200** (USB interface cable w/ 3.5mm headphone plug)

Operates with Standard MadgeTech data loggers which includes all products **except**:  
 Cryo-Temp, TransiTemp-EC, TransiTempII, TransiTempII-RH, WineSafe, MicroTemp and MicroRHTemp

#### **IFC110** (9-pin serial interface cable w/ 3.5mm headphone plug)

Operates with Standard MadgeTech data loggers which includes all products **except**:  
 Cryo-Temp, TransiTemp-EC, TransiTempII, TransiTempII-RH, WineSafe, MicroTemp and MicroRHTemp

#### **IFC102** (9-pin serial interface cable w/ 3.5mm headphone plug and 3.5 to 2.5mm adapter)

Operates with the MicroTemp and MicroRHTemp **only**.

#### **IFC202** (USB interface cable w/ 3.5mm headphone plug and 3.5mm to 2.5mm adapter)

Operates with the MicroTemp and MicroRHTemp **only**.

**IFC103** (9-pin serial interface cable with special interface, base station)

Operates with the TransiTemp-EC (single and multi use) **only**.

(The interface on the IFC103 interface/base station is a hard-wired, 9-pin serial plug. This part number requires the use of a USB to Serial adapter to become USB capable. We offer the USB-1, USB to Serial Adapter that will work with this cable to convert it to USB)

**IFC300** (USB docking station with magnetic wand)

Operates with the Cryo-Temp, TransiTempII, TransiTempII-RH, and WineSafe **only**.

**RFC101A** - (RF, wireless receiver for use with RF loggers.)

Operates with the RF Series data loggers **only**.

(The interface on this receiver is a hard-wired, 9-pin serial plug. This part number requires the use of a USB to Serial adapter to become USB capable. We offer the USB-1, USB to Serial Adapter that will work with this device to convert it to USB. Necessary for the following loggers)

MadgeTech, Inc.  
(603) 456-2011 Phone  
(603) 456-2012 Fax  
www.madgetech.com  
support@madgetech.com

879 Maple Street,  
Contoocook, NH 03229

PO Box 50  
Warner NH 03278